

# **HOMELINK PROGRAMING INSTRUCTIONS**

## Step 1.

### Preparing Homelink system.

Press and hold two outside buttons on homelink system in car. Wait for light to change from slow flashing or solid light to a rapid flash. Release buttons.

## Step 2.

### Programming handheld remote to homelink system.

Make sure path for door is clear. Door will activate during this step.

Hold the handheld remote next to desired Homelink button. Press and hold both until slow flashing or solid light turns to rapid flash. Release buttons.

Programming is now complete for non rolling code openers. Go to step 3 for rolling code openers.

## Step 3.

### Rolling code or learn button programming.

\*\*Use this step only with rolling code type openers.\*\*

Find the learn code button on your Garage door opener.

Press and release. Return to your car. Press and release desired button on Homelink system 4 times or until door activates. Programming is now complete.

#### **Non rolling code openers:**

Genie blue max CM7500 or 8500

Hillomatic / Monarch

Link 2000

Powerlift

#### **Rolling code openers**

Genie Pro. CM7600 OR 8600

Genie Stealth

Hoermann

**Homelink 1-800-355-3515 or [www.homelink.com](http://www.homelink.com)**